


AXIS F4005 Dome Sensor Unit


Installation Guide




1x



4x




1x



1x







1x




1x


AXIS F4005 Dome Sensor Unit









1.1




1.2







2.1




2.2




2.3




3.1




3.2



3.3




3.4





3.5

4x



3.6





Installation Guide

AXIS F4005 Dome Sensor Unit

© Axis Communications AB, 2016

Ver. M1.3

Date: February 2016

Part No. 1562035